

(I) Boeing (McDonnell Douglas) DC-9 Series**I Additional Requirements and Special Conditions****1.1 Applicable** to McDonnell Douglas DC-9 Series 10 and 30.**Comparator Warning Indicator**

Comparator warning indicators are required for the two main attitude indicators and the comparison is to be made at the instrument presentation. The independence of these systems shall not be violated by the comparator. Annunciation must be adjacent to each pilot's ADI.